



Thank You for Ordering Your Replacement Filter Set

Model: HRTXFILTERSET

Includes: Aluminum Mesh & Charcoal Combination Filters (2)

We appreciate you choosing our replacement filters to keep your range hood performing at its best. For a quick and easy installation, please follow the enclosed step-by-step instructions.

Range Hood Filters:


Your range hood is equipped with two filters. One is fixed to the range hood. The other is in the retractable tray.

- The aluminum mesh cassette holds oils and dust from the air while the charcoal filter layer helps remove smoke and odors.
- **The filters cannot be cleaned and must be replaced.**

CAUTION: Ensure the range hood is disconnected from the power supply and all surfaces are cool before cleaning any part of the vent hood.

Instructions:

1. Ensure the range hood is disconnected and all surfaces are cool.
2. Remove the screws that hold the **fixed filter** in place.
3. Click the spring clamps then gently pull it out of the frame.
4. Pull out the retractable tray to remove the **retractable filter**.
5. Insert the new filters in place.



IMPORTANT: The filters are NOT dishwasher safe and must be replaced every 6-12 months depending on usage.

To Purchase Replacement Filters:

Call us at **(718) 893-3900**

or order directly at: <https://summitapplianceparts.com/HRTXFILTERSET/>

If you need help with your installation call our Customer Service facility at **800-932-4267 (Ext. 513)** between 9:00 AM and 5:00 PM ET or visit our website summitappliance.com/support at any time. We will do our best to answer your questions.